

Panel PC's



Industrial PC's



SBC's



Electronic Design



Industrial Displays



Embedding the future



Why Choose DSL?

- ✓ Lifetime technical support
- ✓ Fully customisable products
- ✓ Product branding (bezel colours + company logos)
- ✓ Free pre-installation of OS and your software



Our Services

- ✓ Electronic Design
- ✓ Production Management
- ✓ Assembly and test
- ✓ Bespoke BIOS creation



sales@dsl-ltd.co.uk

or call us on +44 (0)1462 675530





User's Manual

PPC-090T

DMP Vortex86 DX2 Processor

Compact Panel PC with 9" Touchscreen

PPC-090T-D2N3N

PPC-090T-D2N4N

PPC-090T-D2N3N-GE

PPC-090T-D2N4N-GE

PPC-090T-D2W4N

PPC-090T-D2W4N-GE

(Revision 1.2A)

REVISION

DATE	VERSION	DESCRIPTION
2014/1/22	Version 1.0A	New Release
2014/3/11	Version 1.1A	Add 4.3 Serial Ports Setting (RS232/422/485)
2015/9/15	Version 1.2A	Change the SPEC of Section 3.1

COPYRIGHT

The information in this manual is subject to change without notice for continuous improvement in the product. All rights are reserved. The manufacturer assumes no responsibility for any inaccuracies that may be contained in this document, and makes no commitment to update or to keep current the information contained in this manual.

No part of this manual may be reproduced, copied, translated or transmitted, in whole or in part, in any form or by any means without the prior written permission of the ICOP Technology Inc.

©Copyright 2015 ICOP Technology Inc.
Manual # IUMPPC090T-01 Ver.1.2A Sep, 2015

TRADEMARKS ACKNOWLEDGMENT

Vortex86DX2™ is the registered trademark of DMP Electronics Inc. Other brand names or product names appearing in this document are the properties and registered trademarks of their respective owners. All names mentioned herewith are served for identification purpose only.

For more detailed information or if you are interested in other ICOP products, please visit our official websites at:

- Global: www.icop.com.tw
- USA: www.icoptech.com
- Japan: www.icop.co.jp
- BV: www.icoptech.eu
- China: www.icop.com.cn

For technical support or demo images of operating systems download, please visit our websites at:

- ICOP Technical Resource: <http://tech.icop.com.tw/>
- Software Support: <http://www.icoptech.net/>

This Manual is for the PPC-090T.

SAFETY INFORMATION

- Read these Safety instructions carefully.
- Please carry the unit with both hands, handle carefully.
- Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
- Do not expose your Panel PC to rain or moisture in order to prevent shock and fire hazard.
- Input voltage rated +12 ~ 24 VDC
- Operating temperature between 0~+50°C (+32~+122°F).
- Keep PPC-090T away from humidity.
- When a Compact Flash Card or a SATA Slim is the main operating system storage, please turn off power before inserting or removing. Do not open the cabinet to avoid electrical shock. Refer to your nearest dealer for qualified personnel servicing.
- Never touch un-insulated terminals or wire unless your power adaptor is disconnected.
- Locate your Panel PC as close as possible to the socket outline for easy access and to avoid force caused by entangling of your arms with surrounding cables from the Panel PC.
- USB connectors are not supplied with Limited Power Sources.
- If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.

WARNING!



DO NOT ATTEMPT TO OPEN OR TO DISASSEMBLE THE CHASSIS (ENCASING) OF THIS PRODUCT. PLEASE CONTACT YOUR DEALER FOR SERVICING FROM QUALIFIED TECHNICIAN.

Content

Content	iii
Ch. 1 General Information	1
1.1 Product Description	2
1.2 Product Specifications.....	3
1.3 Inspection standard for TFT-LCD Panel.....	5
1.4 Product Dimensions.....	8
1.5 Panel Mounting Instruction	10
1.6 Ordering Information.....	12
Ch. 2 System Installation.....	13
2.1 CPU Board Outline	14
2.2 Connector Summary.....	15
2.3 Connector Pin Assignments.....	16
2.4 External I/O Overview	18
2.5 External I/O Pin Assignment	19
2.6 Watchdog Timer.....	20
Ch. 3 Hardware Installation	21
3.1 Installing the SATA Slim	22
3.2 Installing the Compact Flash.....	24
Ch. 4 Driver Installation	25
4.1 PPC-090T Development Note	27
4.2 BIOS Default Setting.....	28
4.3 Serial Ports Setting (RS232/422/485)	29
Warranty	32

Ch. 1

General Information

[1.1 Product Description](#)

[1.2 Product Specifications](#)

[1.3 Inspection standard for TFT-LCD Panel](#)

[1.4 Product Dimensions](#)

[1.5 Mounting Instruction](#)

[1.6 Ordering Information](#)

1.1 Product Description

ICOP Technology Inc. is proudly going to release a brand new Panel PC, which offers fanless design, low power consumption, and IP65 front panel. The PPC-090T is powered by DMP's latest Vortex86DX2 SoC, the 3rd generation SoC of Vortex86 family, and dual-channel 1GB DDRII chipset that handles processing more efficiently and provides faster performance. The resistive touch panel with LED backlight TFT LCD increases operation convenience and visibility in outdoor environments. The ultra-compact and thin exterior design is perfect for the present demanding embedded and productive applications.

The new PPC-090T inherited PDX/PMX-series' smooth appearance and ultra-texture aluminum exterior design to make your industrial applications look more stylish. The versatile I/O ports, IP65 front panel, 10/100Mps Ethernet, GIGA high-speed Ethernet, WiFi, etc. can fulfill fundamental functions. Our consistent advantages feature stable performance, extended working temperature support, low power consumption and fanless design. The expandable customize I/O ports can be accommodated connectivity requirements to industrial machine platforms and industrial automation equipment's needs.

The PPC-090T supports Windows Embedded CE, Windows Embedded Standard 2009, Windows Embedded Compact 7, and Linux to meet ready-to-market demand and provide competitive advantages for customers.

1.2 Product Specifications

CPU BOARD SPECIFICATIONS

CPU	DM&P Vortex86DX2 933MHz
Cache	L1:16KB I-Cache, 16KB D-Cache L2: 256KB Cache
BIOS	AMI BIOS
Memory	512MB / 1GB DDR2 onboard
Watchdog Timer	Software Programmable from 30.5u to 512 seconds x 2 sets
LAN	Integrated 10/100M Ethernet X1 Giga Ethernet (Optional) X1
Audio	HD Audio-Realtek ALC262 CODEC
Internal Drives	Compact Flash Type I / II Slot, SATA SLIM SD Slot (Optional)
I/O	RS-232/422/485 x 2 USB Ports (Ver2.0) x 3 PS/2 KB Audio-Out RJ-45 Port x 1 GIGA Ethernet Port X 1 (Optional)

MECHANICAL & ENVIRONMENT

Power Requirement	+12 ~ 24VDC
Power Consumption	+24VDC@ 1A
Operating Temperature	0~+50°C (+32~+122°F) / -20~+60°C (-4~+140°F)

Storage Temperature	-30~+70°C (-22~ +158°F)
Operating Humidity	0% ~ 90% Relative Humidity, Non-Condensing
Dimensions	242x156.5x44mm (9.68"x6.26"x1.76")
Weight	3.0 Kg
Protection	IP65 Front Panel
Certification	CE / FCC / VCCI / Vibration

LCD SPECIFICATIONS

Display Type	9" WSVGA TFT LCD
Backlight Unit	LED
Display Resolution	1024(W) x 600(H)
Brightness (cd/m ²)	300 nits
Contrast Ratio	500 : 1
Display Color	262,144
Pixel Pitch (mm)	190.5 (H) x 189 (V)
Viewing Angle	Vertical 140°, Horizontal 160°
Backlight Lifetime	25,000 hrs

TOUCHSCREEN

Type	Analog Resistive
Resolution	Continuous
Transmittance	80%
Controller	PS/2 interface
Software Driver	Linux / WinCE / Windows XP
Durability	1 million

1.3 Inspection standard for TFT-LCD Panel



DEFECT TYPE			LIMIT				Note	
VISUAL DEFECT	INTERNAL	SPOT	$\varphi < 0.15\text{mm}$		Ignore			
			$0.15\text{mm} \leq \varphi \leq 0.5\text{mm}$		$N \leq 4$		Note 1	
			$0.5\text{mm} < \varphi$		$N=0$			
		FIBER	$0.03\text{mm} < W \leq 0.1\text{mm}, L \leq 5\text{mm}$			$N \leq 3$	Note 1	
			$1.0\text{mm} < W, 1.5\text{mm} < L$			$N=0$		
		POLARIZER BUBBLE	$\varphi < 0.15\text{mm}$		Ignore		Note 1	
			$0.15\text{mm} \leq \varphi \leq 0.5\text{mm}$		$N \leq 2$			
			$0.5\text{mm} < \varphi$		$N=0$			
		Mura	It's OK if mura is slight visible through 6%ND filter					
ELECTRICAL DEFECT		BRIGHT DOT	A Grade			B Grade		
			C Area	O Area	Total	C Area	O Area	
			$N \leq 0$	$N \leq 2$	$N \leq 2$	$N \leq 2$	$N \leq 3$	
		DARK DOT	$N \leq 2$	$N \leq 3$	$N \leq 3$	$N \leq 3$	$N \leq 5$	
		TOTAL DOT	$N \leq 4$			$N \leq 5$	$N \leq 6$	
		TWO ADJACENT DOT	$N \leq 0$	$N \leq 1$ pair	$N \leq 1$ pair	$N \leq 1$ pair	$N \leq 1$ pair	
		THREE OR MORE ADJACENT DOT	NOT ALLOWED					
		LINE DEFECT	NOT ALLOWED					

(1) One pixel consists of 3 sub-pixels, including R, G, and B dot. (Sub-pixel = Dot)

(2) Little bright Dot acceptable under 6% ND-Filter.


(3) If require G0 grand (Total dot $N \leq 0$), please contact region sales.

[Note 1] W: Width[mm]; L: Length[mm]; N: Number; φ : Average Diameter.




(a) White / Black Spot (b) Polarizer Bubble

[Note 2] Bright dot is defined through 6% transmission ND Filter as following.




[Note 3] Display area



C Area: Center of display area **O Area:** Outer of display area

[Note 4] Judge the defect dot and the adjacent dot as following. Allow below (as A, B, C and D status) adjacent defect dots, including bright and dark adjacent dot. And they will be counted 2 defect dots in total quantity.




The defects that are not defined above and considered to be problem shall be reviewed and discussed by both parties.

Defects on the Black Matrix, out of Display area, are not considered as a defect or counted.


1.4 Product Dimensions

Appearance Diagram



Appearance Diagram


5 DEKEMBRE 2000 3




2010-01-05 Rev.02		1	
2		3	
4		5	
6		7	
8		9	
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57			
58			
59			
60			
61			
62			
63			
64			
65			
66			
67			
68			
69			
70			
71			
72			
73			
74			
75			
76			
77			
78			
79			
80			
81			
82			
83			
84			
85			
86			
87			
88			
89			
90			
91			
92			
93			
94			
95			
96			
97			
98			
99			
100			
101			
102			
103			
104			
105			
106			
107			
108			
109			
110			
111			
112			
113			
114			
115			
116			
117			
118			
119			
120			
121			
122			
123			
124			
125			
126			
127			
128			
129			
130			
131			
132			
133			
134			
135			
136			
137			
138			
139			
140			
141			
142			
143			
144			
145			
146			
147			
148			
149			
150			
151			
152			
153			
154			
155			
156			
157			
158			
159			
160			
161			
162			
163			
164			
165			
166			
167			
168			
169			
170			
171			
172			
173			
174			
175			
176			
177			
178			
179			
180			
181			
182			
183			
184			
185			
186			
187			
188			
189			
190			
191			
192			
193			
194			
195			
196			
197			
198			
199			
200			
201			
202			
203			
204			
205			
206			
207			
208			
209			
210			
211			
212			
213			
214			
215			
216			
217			
218			
219			
220			
221			
222			
223			
224			
225			
226			
227			
228			
229			
230			
231			
232			
233			
234			
235			
236			
237			
238			
239			
240			
241			
242			
243			
244			
245			
246			
247			
248			
249			
250			
251			
252			
253			
254			
255			
256			
257			
258			
259			
260			
261			
262			
263			
264			
265			
266			
267			
268			
269			
270			
271			
272			
273			
274			
275			
276			
277			
278			
279			
280			
281			
282			
283			
284			
285			
286			
287			
288			
289			
290			
291			
292			
293			
294			
295			
296			
297			
298			
299			
300			
301			
302			
303			
304			
305			
306			
307			
308			
309			
310			
311			
312			
313			
314			
315			
316			
317			
318			
319			
320			
321			
322			
323			
324			
325			
326			
327			
328			
329			
330			
331			
332			
333			
334			
335			
336			
337			
338			
339			
340			
341			
342			
343			
344			
345			
346			
347			
348			
349			
350			
351			
352			
353			
354			
355			
356			
357			
358			
359			
360			
361			
362			
363			
364			
365			
366			
367			
368			
369			
370			
371			
372			
373			
374			
375			
376			
377			
378			
379			
380			
381			
382			
383			
384			
385			
386			
387			
388			
389			
390			
391			
392			
393			
394			
395			
396			
397			
398			
399			
400			
401			
402			
403			
404			
405			
406			
407			
408			
409			
410			
411			
412			
413			
414			
415			
416			
417			
418			
419			
420			
421			
422			
423			
424			
425			
426			
427			
428			
429			
430			
431			
432			
433			
434			
435			
436			
437			
438			
439			
440			
441			
442			
443			
444			
445			
446			
447			
448			
449			
450			
451			
452			
453			
454			
455			
456			
457			
458			
459			
460			
461			
462			
463			
464			
465			
466			
467			
468			
469			
470			
471			
472			
473			
474			
475			
476			
477			
478			
479			
480			
481			
482			
483			
484			
485			
486			
487			
488			
489			
490			
491			
492			
493			
494			
495			
496			
497			
498			
499			
500			
501			
502			
503			
504			
505			
506			
507			
508			
509			
510			
511			
512			
513			
514			
515			
516			
517			
518			
519			
520			
521			
522			
523			
524			
525			
526			
527			
528			
529			
530			
531			
532			
533			
534			
535			
536			
537			
538			
539			
540			
541			

1.5 Panel Mounting Instruction


1. Cut a mounting hole in the panel. (Refer to [PPC-090T Dimensions](#) on page 11~12.) (Note 1)
2. Check and remove the twelve M3 screws in a diagonal pattern as image below if necessary.
3. Place PPC-090T face-down on a clean, flat surface.
4. Slide the panel cutout around the back of PPC-090T, until the panel rests directly on the gasket. Make sure the screw holes align with the screw holes on PPC-090T.
5. The screw size is M3*L (L=wall thickness + 6.0mm) (Note 2)
6. Insert all twelve M3 screws into the screw holes. (Note 2)
7. Finger-tighten the M3 screws. Finish tightening the M3 screws in a diagonal pattern using an M3 screw driver (see the image as below); maximum torque 1.18Nm (12 kgf-cm).





Note 1:

It is strongly recommended that a professional machine shop cut the mounting hole in the panel.



Note 2:

The length for all twelve M3 screws will be according to the thickness of mounting panel. For example: The length of standard M3 screws for PPC-090T is 6mm. If the thickness of your mounting panel is 3mm and washer thickness is 1mm, you have to use 10mm M3 screw.

1.6 Ordering Information

PART NUMBER	DESCRIPTION
PPC-090T-D2N	9" Panel PC w/1GB Memory 3USB/AUDIO/LAN/2COM/DC12~24V
PPC-090T-D2N-GE	9" Panel PC w/1GB Memory 3USB/AUDIO/LAN/GIGA LAN/2COM/ DC12~24V
PPC-090T-D2W	9" Panel PC w/1GB Memory 3USB/AUDIO/LAN/2COM/DC12~24V/ Wide Temp
PPC-090T-D2W-GE	9" Panel PC w/1GB Memory 3USB/AUDIO/LAN/GIGA LAN/2COM/ DC12~24V/Wide Temp

PACKING LIST

PART NUMBER	PACKAGE	
PPC-090T-D2N	PPC-090T-D2N *1	M4 L8 Screw *4
PPC-090T-D2N-GE	PPC-090T-D2N-GE *1	M4 L8 Screw *4
PPC-090T-D2W	PPC-090T-D2W *1	M4 L8 Screw *4
PPC-090T-D2W-GE	PPC-090T-D2W-GE *1	M4 L8 Screw *4

Ch. 2

System Installation

[2.1 CPU Board Outline](#)

[2.2 Connector Summary](#)


[2.3 Connector Pin Assignments](#)

[2.4 External I/O Overview](#)

[2.5 External I/O Pin Assignment](#)

[2.6 Watchdog Timer](#)

2.1 CPU Board Outline



2.2 Connector Summary

No.	Description	Type of Connections	Pin #
J1	Power Terminal Connector	External Power Plug	3-pin
J3	COM (RS232/422/485)	External D-Sub Male Connector	9-pin
J4	USB	External USB Connector	6-pin
J5	USB	External USB Connector	6-pin
J6	PS/2Keyboard	External Mini DIN Socket	6-pin
J7	USB	External USB Connector	6-pin
J8	USB (Wi-Fi Optional)	Internal USB Connector	5-pin
J11	Ethernet	External RJ45 Connector	8-pin
J12	GIGA Ethernet	External RJ45 Connector	8-pin
J14	RS-232-422-485	2.0mm 10-pin box header	10-pin
J16	SD Card Slot (Optional)	Internal SD Card Socket	
J19	RS-232-422-485 (VGA)	2.0mm 10-pin box header	10-pin
J25	SATA Slim Slot	Internal SATA Slim Socket	
J30	Audio Line-Out	1.25mm Phone Jack	2-pin
J33	GPIO-X3	PH2*25F(2.0)-7.5mm/P2N71-2XX	50-pin
J34	GPIO-X1	PH2*25F(2.0)-7.5mm/P2N71-2XX	50-pin
J35	GPIO-X4	PH2*15F(2.0)-7.5mm/P2N71-2XX	30-pin
J36	GPIO-X2	PH2*25F(2.0)-7.5mm/P2N71-2XX	50-pin
CF1	CF Card Socket	CF Type I/II Socket	

2.3 Connector Pin

Assignments

J1: Power Terminal Connector

Pin #	Signal Name
1	+12~24V
2	GND
3	FG

J7: USB

Pin #	Signal Name	Pin #	Signal Name
1	VCC	2	USBD4-
3	USBD4+	4	GND
5	GND	6	GND

J3: COM (RS232/422/485)

Pin #	Signal Name	Pin #	Signal Name
1	DCD1/422TX-/RS485-	2	RXD1/422TX+ /RS485+
3	TXD1/422RX+	4	DTR1/422RX-
5	GND	6	DSR1
7	RTS1	8	CTS1
9	RI1		

J4: USB

Pin #	Signal Name	Pin #	Signal Name
1	VCC	2	USBD2-
3	USBD2+	4	GND
5	GND	6	GND

J5: USB

Pin #	Signal Name	Pin #	Signal Name
1	VCC	2	USBD3-
3	USBD3+	4	GND
5	GND	6	GND

J8: USB (Wi-Fi Optional)

Pin #	Signal Name	Pin #	Signal Name
1	VCC	2	USBD1-
3	USBD1+	4	GND
5	GND		

J6 : PS/2Keyboard

Pin #	Signal Name	Pin #	Signal Name
1	KBCLK	2	MSCLK
3	GND	4	KBDATA
5	MSDATA	6	VCC
7	GND	8	GND
9	GND		


J19: RS-232-422-485

Pin #	Signal Name	Pin #	Signal Name
1	R OUT	2	GND
3	G OUT	4	GND
5	B OUT	6	GND
7	H SYNC	8	GND
9	V SYNC	10	GND

J33/J34/J35/J36: GPIO 180-pin

J33				J34				J35				J36			
Pin#	Signal Name														
1	GND	2	GND	1	GND	2	SBHE	1	VCC	2	VCC	1	SA7	2	SA6
3	GP34	4	GP35	3	RSTDRV	4	SD7	3	GND	4	GND	3	IRQ3	4	SA5
5	GP36	6	GP37	5	VCC	6	SD6	5	GP90	6	GP91	5	IRQ10	6	SA4
7	GP40	8	GP41	7	SD8	8	SD5	7	GP92	8	GP93	7	IRQ11	8	SA3
9	GP42	10	GP43	9	SD9	10	SD4	9	GP94	10	GP95	9	IRQ12	10	SA2
11	GP44	12	GP45	11	SD10	12	SD3	11	GP96	12	GP97	11	BALE	12	SA1
13	GP46	14	GP47	13	SD11	14	SD2	13	GPCS0	14	GPCS1	13	OSC	14	SA0
15	GP50	16	GP51	15	SD12	16	SD1	15	GP00	16	GP01	15	GND	16	IQ14
17	GP52	18	GP53	17	SD13	18	SD0	17	GP02	18	GP03	17	GP10	18	GND
19	GP54	20	GP55	19	GND	20	GND	19	GP04	20	GP05	19	GP12	20	GP11
21	GP56	22	GP57	21	SMEMW	22	IOCHRDY	21	GP06	22	GP07	21	GP14	22	GP13
23	GND	24	GND	23	SMEMR	24	AEN	23	RS485+1	24	RS485-1	23	GP16	24	GP15
25	GP60	26	GP61	25	IOW	26	SA19	25	VBATT	26	FGND	25	GP20	26	GP17
27	GP62	28	GP63	27	IOR	28	SA18	27	VIN	28	VIN-	27	GP22	28	GP21
29	GP34	30	GP65	29	SD14	30	SA17	29	VIN	30	VIN-	29	GP24	30	GP23
31	GP66	32	GP57	31	SD15	32	SA16					31	GP26	32	GP25
33	GP70	34	GP71	33	MEMCS16	34	SA15					33	GP30	34	GP27
35	GP72	36	GP73	35	IOCS16	36	SA14					35	GP32	36	GP31
37	GP74	38	GP75	37	REFRESH	38	SA13					37	XPCIRST-	38	GP33
39	GP76	40	GP77	39	GND	40	SA12					39	GND	40	GND
41	GP80	42	GP81	41	SYSCLK	42	SA11					41	XPE0_RX-	42	XPE0_TX-
43	GP82	44	GP83	43	IRQ7	44	SA10					43	XPE0_RX+	44	XPE0_TX+
45	GP84	46	GP85	45	IRQ6	46	SA9					45	GND	46	GND
47	GP86	48	GP87	47	IRQ5	48	SA8					47	XYPE0_CLK-	48	XUSBD3-
49	GND	50	GND	49	IRQ4	50	GND					49	XYPE0_CLK+	50	XUSBD3+

2.4 External I/O Overview



NOTE

1. GIGA LAN, Wireless are optional
2. RS232/422/485 is selected by BIOS setting

2.5 External I/O Pin

Assignment

Power Switch

	Pin #	Status
	1	ON
	0	OFF

Power Connector DC-IN 24V

	Pin #	Signal Name
	1	+12~24V
	2	GND
	3	FG

PS/2 Keyboard

	Pin #	Signal Name
	1	KBCLK
	2	PMCLK
	3	GND
	4	KBDAT
	5	PMDAT
	6	SB5V

J3: COM-RS232/422/485

(Change setting by BIOS)

	Pin #	Signal Name	Pin #	Signal Name
	1	DCD1/422	2	RXD1/422
	1	TX-/RS48	2	TX+/RS48
		5-		5+
	3	TXD1 / 422RX+	4	DTR1 / 422RX-
	5	GND	6	DSR1
	7	RTS1	8	CTS1
	9	RI1		

J4/J5/J7: USB

	Pin #	Signal Name
	1	VCC
	2	USB0-
	3	USB0+
	4	GND
	5	GGND
	6	GGND

RJ45

	Pin #	Signal Name	Pin #	Signal Name
	1	FTXD+	2	FTXD-
	3	FRXIN+	4	NC
	5	NC	6	FRXIN-
	7	NC	8	NC

GIGA Ethernet (Optional)

	Pin #	Signal Name	Pin #	Signal Name
	1	FTXD+	2	FTXD-
	3	FRXIN+	4	NC
	5	NC	6	FRXIN-
	7	NC	8	NC

Audio Line-Out

	Pin #	Signal Name
	1	GND
	2	LOUTL
	3	Open Touch
	4	Open Touch
	5	VREFOUT

2.6 Watchdog Timer

There are two watchdog timers in PPC-090T, we also provide DOS, Linux and WinCE example for your reference.

For more technical support, please visit: <http://tech.icop.com.tw> or download the PDF file: dmp.com.tw/tech

Ch. 3

Hardware Installation

PPC-090T supports various kinds of storages for industrial application, divided into SATA Slim, CompactFlash or SD card (optional).

[3.1 Installing the SATA Slim](#)

[3.2 Installing the Compact Flash](#)

3.1 Installing the SATA Slim


[SPEC]

JEDEC SFF-8156 standard form factor
53 x 32 x 4.0 mm
SDM-SST-SLIM(M)4G
SDM-SST-SLIM(M)8G
SDM-SST-SLIM(M)16G
SDM-SST-SLIM(M)32G




[STEP]

1. Remove the nine screws in a diagonal pattern as the image below.



2. Place the SATA slim horizontally aligned and gently put into the socket until you feel a click.




3. Insert all nine screws into the screw holes.

3.2 Installing the Compact Flash

[STEP]

1. Remove the nine screws in a diagonal pattern as the image below.



2. Gently insert the CF card along the track. Caution: Please watch out for the direction which the CF card has to be face up.



3. Insert all nine screws into the screw holes.

Ch. 4

Driver Installation

[4.1 PPC-090T Development Note](#)

[4.2 BIOS Default Setting](#)

[4.3 Serial Ports Setting \(RS232/RS422/RS485\)](#)

VGA

The Vortex86DX2 processor is integrated RDC Display chip which is an ultra-low powered graphics chipset with total power consumption at around 1-1.5 W.

LAN

The Vortex86DX2 processor is integrated 10/100Mbps Ethernet controller that supports both 10/100BASE-T and allows direct connection to your 10/100Mbps Ethernet based Local Area Network for full interaction with local servers, wide area networks such as the Internet.

I/O and IRQ settings can be done by software with the supplied utility software, or it can be set for Plug and Play compatibility. The controller supports: Half / Full-Duplex Ethernet function to double channel bandwidth, auto media detection.

AUDIO

The ALC262 series are 4-Channel High Definition Audio Codecs with UAA (Universal Audio Architecture) featuring two 24-bit stereo DACs and three 20-bit stereo ADCs, they are designed for high performance multimedia desktop and laptop systems. The ALC262 series incorporates proprietary converter technology to achieve over 100dB Signal-to-Noise ratio playback quality; easily meeting PC2001 requirements and also bringing PC sound quality closer to consumer electronic devices.

OPERATING SYSTEM SUPPORT

The PPC-090T provides the VGA and LAN drivers for Linux, Windows CE, Windows XP Professional, and Windows Embedded standard (XPE).

(Linux can use with Compact Flash card only.)

Please get the drivers from ICOP technical support URL: tech.icop.com.tw

PPC-090T also supports most of the popular Linux distributions, for more detail information, please visit DMP official website: vortex86dx2

4.1 PPC-090T Development Note

< WINDOWS DEVELOPMENT GUIDE >

Windows Embedded CE 6.0 BSP, Windows Embedded Compact 7 BSP, and Windows Embedded Standard 2009 trial image with development notes, please visit technical website to get more information at <http://tech.icop.com.tw/>.

< LINUX INSTALLATION NOTE>

Please visit Linux technical website to get more information at ftp://ftp.dmp.com.tw/Linux_DEMO/Vortex86_Linux_Support_List_revised.htm.

4.2 BIOS Default Setting

If the system cannot be booted after BIOS changes are made, Please follow below procedures in order to restore the CMOS as default setting.



Press < **End** > Key, when the power on



Press < **Del** > to enter the AMI BIOS setup



Press < **F9** > to Load Optimized defaults




Press < **F10** > to Save configuration changes
and exit setup


4.3 Serial Ports Setting (RS232/422/485)

Please press to get into the BIOS settings after booting the machine, and follow the steps below:


[Step 1] Use the arrow key to select the category “Chipset” on the top of the menu, then select SouthBridge Configuration in the sub menu and press <Enter>




[Step 2] Use the arrow key to select “TXDEN Serial Port Type Configuration” and press <ENTER>




[Step 3] Choose the port you would like to change. For example, choose TXDEN1 for COM1 and press <Enter>. You will then see three options; select the desired type and press <Enter> to finish the setting.




The Serial Ports setting is finished



[Step 4] Press **<Esc>** twice to get back to the Top Menu. Use the arrow key to the category “Exit”, and select the option “Save Changes and Exit”.



Press **<Enter>** and choose **[OK]** to keep your changes, then the device will reboot automatically.



Warranty

This product is warranted to be in good working order for a period of one year from the date of purchase. Should this product fail to be in good working order at any time during this period, we will, at our option, replace or repair it at no additional charge except as set forth in the following terms. This warranty does not apply to products damaged by misuse, modifications, accident or disaster. Vendor assumes no liability for any damages, lost profits, lost savings or any other incidental or consequential damage resulting from the use, misuse of, originality to use this product. Vendor will not be liable for any claim made by any other related party. Return authorization must be obtained from the vendor before returned merchandise will be accepted. Authorization can be obtained by calling or faxing the vendor and requesting a Return Merchandise Authorization (RMA) number. Returned goods should always be accompanied by a clear problem description.

All Trademarks appearing in this manuscript are registered trademark of their respective owners. All Specifications are subject to change without notice.
©ICOP Technology Inc. 2015